

Cleaner Air for Passengers
Enhanced HVAC Performance
Easy Installation, Perfect Fit

TYC #: 800188C Replacement for OEM B7277-1CA1A



1. Remove the right side cover by pulling as shown in the picture and set it aside.

2. Remove the bottom cover by pulling down as shown in the picture and set it aside. **<u>08-13 Infiniti G37</u>** 14- Infiniti Q50

14- Infiniti Q60

Estimated Time: 10 min. 08-13 Infiniti EX35/EX37 09-13 Infiniti FX35/FX37/FX50 14- Infiniti QX50/QX70

4. After removal the 7 screws, remove entire glove box by pulling down as shown in the picture.





3. Remove total 7 screws as shown in yellow circle. 4 on top, one each side of glove box and one middle screw. (*note: middle screw requires longer length screw driver.)



5. Unlatch the filter cover by pulling from the right side of cover. Replace with new TYC filter. Ensure the filter arrow is pointing up.

Reinstall in reverse order.

Installation guide pictures are from the **<u>BOLD</u>** vehicle model.

Looking for replacement A/C and heating parts? Visit our website.