



HITCH WIRING KIT

Fitment:
2007-Up Jeep Wrangler JK

Contents:
1. Wiring kit (1)

Caution:
Test all light functions before towing.

STEP 1

Place vehicle in gear and arm the emergency break. Remove rear driver's side taillight.



STEP 2

Disconnect taillight connector as shown.



STEP 3

Connect new loom to male and female connectors.



STEP 4

Fish trailer connector down through taillight opening and past foam isolator panel.



STEP 5

After pulling loom through foam isolator drop connector over frame and insert into the tow hitch plug notch.



STEP 6

Locate small 8mm holes drilled along frame and press in retainer clips. Test all light functions before towing.

