



SIDE ARMOR

FITMENT

87-06 Jeep Wrangler

PARTS INCLUDED

Driver Side Guard (1)

Passenger Side Guard (1)

3/8" x 1" Self Tapping Bolts (16)

TOOLS NEEDED

Ratchet and Socket Set

Drill

Drill Bit Set

CAUTION

Before drilling be sure to check the backside for hazards or obstructions.

To protect your investment, wax this product after installing. Regular waxing is recommended. Do not use any type of polish/wax that contains abrasives that could damage the finish.

STEP 1

Position the guard up to the frame. Maintain a 1/2" minimum gap between the bottom of the vehicle and the top of the guard. Adjust the guard from front to back until it is parallel to the side of the frame while also making sure it is parallel with the side of the vehicle.

(Assistance is recommended)

STEP 2

When you are satisfied with the placement of the guard, mark the side of the frame through the mounting holes located on the guards brackets. After you have marked all the holes place the guard to the side. Center punch the frame at the marked locations and drill a 5/16" hole in the frame.

STEP 3

Position the guard back against the frame and line up the holes in the brackets with the holes that you just drilled on the frame. Secure the guard to the frame using the supplied self tapping bolts. Tighten all bolts at this time.

(Figure 1)



Figure - 1

STEP 4

Installation is now complete. **(Figure 2)**



Figure - 2