

# 1932 DASH TRIM INSTALLATION

For the best possible fit, this trim was made slightly longer than needed, and the ends WILL NEED TO BE FILED for a tight fit in your dash opening. To install start with one end at top center of opening, then insert the trim around the dash opening. File and repeat as necessary for a perfect fit in your dash.

View [other semi truck chrome trim](#) made by [United Pacific](#) on our website.