

# vicrez

## Installation Instructions: Vicrez Rear Diffuser Fins Add-ons

### Required:

- Drill and Bits 3/16

- Brackets, Lug nuts, Screws, & Self-Tapping Screws (Included)



**(1)** Thoroughly clean the OEM rear diffuser to ensure the cleanest possible surface



**(2)** Evenly mark the area where the fins add-ons will be installed



**(3)** Test fit the rear fin add-ons so you are familiar to how it fits. Then remove the 3M tape backing



**(4)** Align the fins accordingly, mark holes & proceed drilling fins for the bracket, use self-tapping screws to attach fins to OEM rear diffuser



**(5)** Close up using provided hardware



**(6)** Final result how the fin add-ons should look