



Instructions

1. Clean area around puncture of dirt and grease.
2. Scuff area thoroughly with metal buffer or sandpaper.
3. Apply cement to buffed area slightly larger than patch to be applied. Work well into rubber and allow to dry.
4. Remove protective backing from patch.
5. Center patch over puncture and apply pressure from the center out to eliminate air bubbles and assure a strong bond.
6. Repair is ready for immediate use.

Note: When inserting plugs, use a generous amount of cement for initial lubrication and ultimate adhesion.

WARNING: This product contains chemicals, including lead, known to the State of California to cause cancer, birth defects or other reproductive harm. *Wash hands after handling.*

DANGER: Flammable. Contains Heptane. Do not use near heat or flame. Vapor harmful, do not inhale or swallow. Avoid contact with eyes and skin. For eye contact, flush with water for 15 minutes. For skin contact, wash thoroughly with soap and water. If swallowed, do not induce vomiting and get immediate medical attention. **KEEP OUT OF REACH OF CHILDREN.**