



# Fast Fit 57636

Jeep

2012-2013 Wrangler 3.6L

---

1. Disconnect the negative battery cable.
2. Lift up and remove the factory engine cover.
3. Disconnect the ATS sensor connection.
4. Remove the breather hose from the factory air duct.
5. Loosen the clamp holding the duct to the throttle body and the clamp holding the duct to the air box, Remove the bolts holding the duct in place than remove the factory ducting.
6. Pull up on the factory [air box](#) and remove.
7. Remove the ATS sensor from the factory air duct.
8. Press the sensor into the rubber grommet on Volant system.
7. Attach filter 5117 to the Volant system.
8. Place the hump hose onto the Volant system and tighten the clamp.
9. Slide the Volant system onto the throttle body and onto the factory air box grommets.
10. Tighten the Volant system to the throttle body and connect the ATS sensor harness.
11. Attach the breather hose to the volant duct.
13. Reattach the negative battery cable.