



NOTE: REMOVE ALL SIX FACTORY PUSH PINS FROM THE RADIATOR CORE SUPPORT AND REMOVE PLASTIC COVER. PLACE THE VOLANT RAM AIR SCOOP OVER THE CORE SUPPORT AND FASTEN WITH 3 FACTORY PUSH PINS.

If you're looking for quality performance air intake systems, visit our website.