



**P/N 725062**  
**Chevrolet Camaro**  
**2010 - 2013 6.2L**

1. Disconnect the negative battery cable.
2. Remove the breather hose from the air duct and disconnect the MAF sensor harness.
3. Loosen the clamp holding the air duct to the throttle body and air box. Than remove the duct.
4. Remove the 4 10mm bolts holding the throttle body in place and set the throttle body aside.
5. Press the Vortice [throttle body spacer](#) into the manifold.
6. Place the gasket between the spacer and the throttle body.
7. Tighten the throttle body to the manifold using the provided hardware.
8. Reattach the air duct to the throttle body and air box.
9. Reattach the breather hose and MAF sensor harness.
10. Reattach the negative battery cable.

