



**P/N 727636**

**Chrysler 300 11-13 3.6L  
Dodge Challenger, Charger,  
Durango 11-13 3.6L  
Jeep Grand Cherokee 11-13 3.6L  
Jeep Wrangler 12-13 3.6L**

---

1. Disconnect the negative battery cable. Remove the engine cover.
2. Disconnect the ATS sensor harness from the sensor
3. For Wrangler models remove the 2 bolts holding the air duct in place.
4. Loosen the clamp holding the duct to the throttle body and the clamp holding the duct to the air box.
5. Remove the 4 bolts holding the throttle body and set it aside.
6. Press the [throttle body spacer](#) into the manifold and place the gasket between the the spacer and the throttle body.
7. Tighten the throttle body in place using the hardware provided.
8. Reinstall the duct, ATS sensor, engine cover and battery cable.

