



HOOD SCOOPS

Installation Instruction: For part numbers 13011, 13012, 13001, 13002, 14001

The WADE Hood Scoop has been designed to enhance the appearance of your vehicle. It is VITAL that you read and follow these instructions BEFORE you paint or begin installation.

ATTENTION: YOU MUST FIT PARTS BEFORE PAINTING

To insure proper fit Wade offers three different size Hood Scoops. If your Hood scoops appears too big, or the ends stick out so it can't adhere, you should try a smaller model.

WADE Automotive Products DOES NOT, and WILL NOT accept a return for credit on ANY part that has been PAINTED. THERE WILL BE NO EXCEPTIONS TO THIS RETURN POLICY.

NOTE: Part Number 14001 is only ONE piece. All other part numbers come with both a left and right side.

- 1) Thoroughly wash vehicle but DO NOT WAX. Make sure vehicle is in a warm area of AT LEAST 65 degrees (F) for at least an hour before installation.
 - 2) Due to varying hood designs and contours you will need to decide exactly where to install your HOOD SCOOPS. Do so by placing them on your hood BEFORE you remove the red backing from the tape. Once you have determined exactly where your Hood Scoops should be mark the area with either a wax pencil or masking tape (we recommend masking tape). Remove Hood Scoop.
 - 3) Now with the alcohol pad provided clean the inside edge of the masking taped surface. You may want to apply additional rubbing alcohol to the inside edge (the better your vehicle is prepped the better the hood scoop will adhere to your vehicle).
 - 4) Wearing rubber gloves, lightly and evenly apply the "3M" Adhesion Promoter to the inside of the masking taped edge. When you are finished place the "3M" promoter back into its' package and put it to the side (you need it again).
 - 5) Remove the red backing from one scoop. CAUTION: Once the tape touches the prepped area it will be extremely difficult to remove. MAKE SURE you have the HOOD SCOOPS in the proper position.
 - 6) Place the scoop in the proper position. Start by setting the back edge first and then work your way down. PRESS FIRMLY ON EDGES ALL THE WAY AROUND SCOOP for at LEAST 30 seconds. Repeat step for other side (if applicable). Remove masking tape.
 - 7) Determine which of the inserts goes with which scoop. Clean surface of inner scoop with alcohol and primer. Remove backing from the grill insert and press firmly for at least 30 seconds.
- REMEMBER:** The better you prep your vehicle and the better you insure adhesion, the better the attachment to your vehicle.
- 8) Leave vehicle in warm area for AT LEAST one full hour before driving. Tape will not fully cure for 24 hours. For added security you may consider taping the hood scoop down with masking tape for first 24 hours.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.