

Installation Instruction

Intercooler KIA OPTIMA 2,0T



Kit-Nr.: 200001035

GENERAL NOTES!

WAGNERTUNING

WAGNERTUNING

Important Notes!

These Installation Instruction have to be read careful before beginning installation work. The company WAGNERTUNING bears no liability for damage caused by incorrect installation!

As manufacturer, we are obliged to point out that any changes you make to a vehicle licensed for use on public roads require approval by a test centre and registration in the vehicle documents.

Installation Time (1 unit = 5 minutes)

The installation time is around **24 units**, which may vary depending on vehicle condition and equipment level.

Tools Required

- various spanners
- various screwdrivers

COMPONENTS SUPPLIED

WAGNERTUNING

Part list:

1 intercooler

WAGNERTUNING

INSTALLATION INSTRUCTION

WAGNERTUNING

1. demounting

The demounting of the intercooler made according to the guidelines of the automobile manufacturer.

Remove the front bumper.

Remove the crossmember.

Loosen the connection of the original silicone hoses.

Remove the original air shroud and intercooler.

2. installation

Attach the WAGNERTUNING intercooler at the original mounting points. Connect the silicone hoses to the intercooler.

Install the crossmember.

Install the front bumper.

Check everything is secure and correct.



WAGNERTUNING