



WAGNER TUNING

Installation Instruction

Intercooler

for BMW F20 F30 EVO1



Kit-Nr.: 200001040/046

WAGNERTUNING Intercooler

Important Notes!

These Installation Instruction have to be read careful before beginning installation work. The company Wagner Tuning bears no liability for damage caused by incorrect installation!

As manufacturer, we are obliged to point out that any changes you make to a vehicle licensed for use on public roads require approval by a test centre and registration in the vehicle documents.

Installation Time (1 unit = 5 minutes)

The installation time is around 6 units, which may vary depending on vehicle condition and equipment level.

Tools Required

- various spanners*
- various screwdrivers*

WAGNERTUNING Intercooler

1x Intercooler painted black



2x Hanger Bolts M6x40

2x Hex Nut with Wascher M6)

1x TÜV Certificate

WAGNERTUNING Intercooler

1. demounting

Remove the underfloor protection.
Release the charge air hoses on the intercooler, pull off and lay aside. Remove the standard intercooler.

2. Installation

Install the WAGNERTUNING Intercooler. For attachment use the hanger bolts and hex nuts, which are included to the Kit.

Please be careful, that the guide on the Intercooler is placed correctly.

The plastic panel from the fan has to sit behind the brackets on the intercooler. **(Pos.1)** The lower sealing lip is pressed under the intercooler. **(Pos.2)** Connect the air charge hoses to the intercooler on both sides. Pay attention, that the metal clamps lock at the right position.

Inspect all parts for proper fit. Re-install underfloor protection.

