



WAGNERTUNING

Installation Instruction

Intercooler Kit

Mini Cooper S R56 Facelift



Kit-Nr.: 200001025

WAGNERTUNING

Important Notes!

These Installation Instructions have to be read carefully before beginning installation work. The company Wagner Tuning bears no liability for damage caused by incorrect installation!

As manufacturer, we are obliged to point out that any changes you make to a vehicle licensed for use on public roads require approval by a test centre and registration in the vehicle documents.

Installation Time (1 unit = 5 minutes)

*The installation time is around **12 units**, which may vary depending on vehicle condition and equipment level.*

Tools Required

- various spanners*
- various screwdrivers*
- power drill*
- drill 8 mm*

WAGNERTUNING

parts list:

- 1 *Intercooler*
- 2 *hose clamp 50 - 70mm*
- 1 *rivet M6*
- 1 *allen screw M6x16*
- 1 *washer M6x18*



WAGNERTUNING

1. demounting

The dismantling of the intercooler is done according to the guidelines of the automotive manufacturer.

Remove both front arch liners

Remove the front bumper.

Hose clamps on the air hoses solve OEM intercooler.

Loosen the screws from intercooler (red mark)

Pull out the intercooler.



2. prepare Instalation

Changing the attachment rubber from stock intercooler to the WAGNERTUNING intercooler.



WAGNERTUNING

3. installation

Install the WAGNERTUNING interccoler using the original mounting points. (red mark)

For the upper support point drill an 8 mm hole in the cross member, using the supplied nut, washer and bolt attach the intercooler.

*Attach charge air hoses tight and fasten with the enclosed NORMA hose clamps.
Check for correct and tightness of all installed components.*

To conclude the wheel arches and bumpers corresponding manufacturer's guidelines mount.

