



If wire rope has a terminal on the end, it must be cut off before installing.