



Protecting Your Adventure Lifestyle

Warrior Products, Inc.
16850 SW Upper Boones Ferry Rd
Ste. A
Durham, OR 97224
Phone (888) 220-6861
Fax (503) 692-0364
sales@warriorproducts.com

RECEIVER HITCH

INSTALLATION INSTRUCTIONS

WAR 1085

1. Remove bottom bumper bolts; threaded upwards into bottom of frame.
2. Slide hitch up alongside frame rails, reinstall bumper bolts through hitch into frame to hold hitch in place. DO NOT TIGHTEN.
3. With a " box end wrench, feed supplied " nut through hole in bottom of frame to upper hole, (step #3, figure #1) thread bolt into nut. DO NOT TIGHTEN.
4. Install nut and bolt (step #4, figure #1) into lower center hole. DO NOT TIGHTEN.
5. Tighten the 2 bolts on each side of frame to 65 ft/lbs. Tighten bottom bumper bolts to 65 ft/lbs.
6. Using a " drill bit, drill through frame using hitch hole as a guide (step #6, figure #1).
7. Install last bolts through drilled hole. Tighten to 65 ft/lbs.
8. After test drive re-torque all bolts.

Do not exceed Vehicle Manufacturers Recommended Towing Capacity!

*Load Capacity 2,500 – 5,500 lbs.

If you need further assistance installing your product, please contact us by email at techsupport@warriorproducts.com or call us at (888) 220-6861.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS