



Protecting Your Adventure Lifestyle

BREEZERTOP
INSTALLATION INSTRUCTIONS
WAR1100 / RJR CG505B
CJ5 '55-'75

NOTE: Installation of this top requires footman loops (provided) on top of rear corners.

1. Install footman loops
2. Take Breezer Top, turn it upside down & insert front edge into stock windshield retaining channel, make sure it is fully inserted all the way across
3. Flip Breezer Top over windshield frame and pull towards back of jeep (keeping pressure on top so it won't come loose from channel)
4. Run left and right straps through footman loops & tighten until you have proper tension on the top

Your Breezer Top is now fully installed.

Enjoy your new Maxi-Breezer Top!