



Protecting Your Adventure Lifestyle

BREEZER TOP

INSTALLATION INSTRUCTIONS

WAR 1115 / RJR CG519B

YJ '92-'96

NOTE: Installation of this top requires a windshield retaining channel, if you do not have one it can be purchased at your local offroad shop- Bestop part #51209-01 or OutLand part #90101.

1. Install retaining channel if needed
2. Place Breezer Top over windshield frame top side up
3. Fold the front edge over at a 180 degree angle & insert folded webbing strip into windshield channel making sure it is fully in the channel all the way across
NOTE: It may help to use a rubber mallet to tap the strip into the channel – it is a tight fit
4. Flip the Breezer Top over & pull it towards the rear of the vehicle
5. Wrap & attach rear straps, cinch until you have proper tension on the Breezer Top from front to back
6. Long center strap goes to footman loop on windshield frame
7. Wrap and attach side straps same as rear, cinch until you have proper tension
8. Adjust all straps until you have a tight fit

Your Breezer Top is now fully installed.