



Protecting Your Adventure Lifestyle

MAXI-BREEZER TOP

INSTALLATION INSTRUCTIONS

WAR 1135 / RJR CG529B

YJ'92-'96

NOTE: Installation of this top requires a windshield retaining channel, if you do not have one it can be purchased at your local offroad shop- Bestop part #51209-01 or OutLand part #90101

1. Install the windshield retaining channel if needed
2. Insert folded webbing at front edge into your windshield channel
3. Wrap & attach rear straps, cinch until you have proper tension from front to back
4. Long center strap goes to footman loop on windshield frame
5. Wrap & attach side straps same as rear, cinch until you have proper tension
6. Attach rear straps firmly
7. Adjust all straps until you have a tight fit

Your Breezer Top is now fully installed.