



Protecting Your Adventure Lifestyle

MAXI-BREEZER TOP

INSTALLATION INSTRUCTIONS

WAR 1140 / RJR CG531B

TJ '97-'02

NOTE: Installation of this top requires a windshield retaining channel, if you do not have one it can be purchased at your local offroad shop- Bestop part #51235-01

1. Install the windshield retaining channel if needed
2. Insert folded webbing strip into your windshield channel
3. Attach corner straps, cinch until you have proper tension
4. Attach center strap to footman loop on windshield frame
5. Wrap two shorter straps around Roll Bar & cinch
6. Wrap far rear corner straps around Roll Bar or upper seat belt bolt & cinch until proper tension is attained
7. Make sure rear straps do not interfere with operation of seat belts
8. Adjust all straps until you have a tight fit

Your Maxi-Breezer Top is now fully installed.