



SUBJECT: MIRROR RELOCATION BRACKET INSTALLATION INSTRUCTIONS

Models:

pn1500 – 97-02 TJ WRANGLER

pn1501 – 07-11 JK WRANGLER

pn1505 – 87-96 YJ WRANGLER

Congratulations on your purchase of Warrior Products Windshield Mirror Relocation Bracket for your Jeep. Be sure to open the box and examine the contents before beginning. Read these instructions completely before starting your installation.

1. The Warrior Mirror Relocation Bracket attaches to the front of your windshield, on the lower part of the windshield hinge.
2. Remove the large bolts on the windshield hinge. Remove one bolt at a time, CAREFULLY, to avoid dropping backing nuts located inside the framework.
3. Mount the Warrior Mirror Relocation Bracket using the two (2) stainless steel bolts provided for each side.
4. When finished, be sure to go back and check the tightness of all bolts.
5. Install mirrors into relocation brackets. On YJ and TJ, the nut on the bottom of the mirror holds the mirror into the bracket and is simply unbolted and swapped back and forth easily.
6. On the JK model, this is a torx head bolt instead of a nut. To remove the mirror from the factory mount on the JK you will need to loosen the bolt until it is only slightly threaded and the head of the bolt is protruding below the factory mirror mount.
7. The JK mirror is wedged into place with a taper, much like a steering tie rod end. Do not attempt to lift the mirror out of the mount by hand, you will break the mirror. To free it from the taper tap on the head of the bolt with a mallet upward until the mirror pops free. Remove the bolt and lift the mirror out of the mount.

*** Note:** Mirror relocation brackets are designed to be used when running no doors. Part #1501 is not compatible with the factory full doors or half doors with the upper half in place. You will not be able to open the door with these installed.