



Protecting Your Adventure Lifestyle

HALF DOOR WINDSHIELD BRACKETS

INSTALLATION INSTRUCTIONS

WAR 1525

Congratulations on your purchase of a quality Warrior Products part. Please read the instruction carefully before beginning.

1. Your diamond plate half doors must be mounted onto your Jeep in order to install the brackets properly. The top window portion of your soft top door must be positioned as you want it to fit above your aluminum half door.
2. With the window in the proper position, slide one of the “tall” mounting brackets onto the forward window mounting post. The other short bracket serves as the middle bracket. Slide this bracket onto the middle post. With the bracket flanges pointing towards the rear of the vehicle, mark through the bolt holes onto the half door for drilling.
3. Follow the same procedure for the rear bracket that fits adjacent to the door handle, only with the bracket flange pointing towards the front of the vehicle. The long side of the tube on each bracket points up.
4. Drill six $\frac{1}{2}$ ” holes where you have made your marks and install the brackets using the $\frac{1}{2}$ ” x $\frac{1}{2}$ ” bolts provided. The bolts should be installed with the bolt heads on the outside of the door. Be sure the bolts are tightened securely.
5. Slide your soft top window mounting posts into the brackets and test for proper fit.
6. Congratulations! You have successfully mounted your new brackets. Be sure to review the enclosed catalog for other quality Warrior Products.



PARTS: 6- SHORT BRACKETS
 12- $\frac{1}{2}$ ” X $\frac{3}{4}$ ” BOLTS WITH NUTS AND WASHERS

THANK YOU FOR PURCHASING WARRIOR PRODUCTS

Learn more about armor and protection we have.