



TJ REAR BUMPER

INSTALLATION INSTRUCTIONS

WAR 495, 500, 500C, 50010, 50010C

Bumpers are designed to fit over existing rear cross member support.

1. Remove old bumper from vehicle.
2. Be sure that area where bumper will be mounted is flat and free of any damage.
3. Some TJ's only have two (2) holes on each side drilled, if you are installing a bumper with a hitch you may need to drill two (2) additional holes on each side. Measure from existing holes; mark with a center punch, and drill with a 7/16" drill. Be very careful not to drill into anything that may be behind cross member support. I.e. gas tank cover, wiring. Wear safety glasses.
4. Install new bumper with enclosed hardware. Tighten 7/16" nuts to 50 ft/lbs. Re-torque after your initial test drive.
5. If you have a hitch bumper, check the bumper bolts for tightness prior to and after each use.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS

.....
"Your Knight in Shining Armor!"