

CJ & YJ REAR BUMPER INSTALLATION INSTRUCTIONS

WAR 515, 515C 50510, 50510C, 51510, 51510C

Bumpers are designed to fit over existing rear cross member support.

- 1. Remove old bumperettes from vehicle.
- 2. Be sure that area where bumper will be mounted is flat and free of any damage.
- **3.** Install new bumper with enclosed hardware. Tighten 7/16" nuts to 50ft / lbs. Re-torque after your initial test drive.