



Protecting Your Adventure Lifestyle

BUMPER WITH HITCH INSTALLATION INSTRUCTIONS

WAR 520

1. Remove stock “Bumperettes”. Retain bolts, washers, and nuts for installing your new Bumper.
2. Install Bumper using bolts removed in #1 above. Tighten to manufacturer’s suggested torque. Be sure there is a washer under the bolt head and between the nut and the frame. (Washers are not provided)
3. The two bolts and lock washers provided are to be used on the bottom of the Bumper. Tighten bolts to 50 ft. lbs. torque.