



Protecting Your Adventure Lifestyle

ROCK BARS / KNIGHTGUARD SERIES INSTALLATION INSTRUCTIONS

Congratulations on your purchase of Warrior Products “Rock Bars” or Knightguard for your vehicle. Be sure to open the box and examine the contents before beginning. These instructions should be read completely before starting your installation. Make sure the frame where your Rock Bars/Knightguard will be installed are free of any obstructions, wires, fuel lines, road debris or thick coatings before beginning.

NOTE: BE CAREFUL of fuel line & brake line inside of frame.

1. Hold the Rock Bars up to the frame aligning the rear of the bar to the fender flare.
2. Level the Rock Bars by placing the “L” *shaped flange* **OR** the *Flat shaped flange* tight against the frame. For the Flat shaped flange, raise or lower the other end of the unit until it is level.
3. Mark the frame for drilling through the mounting bracket. Remove the bar to drill the frame. Be sure to use safety glasses for all drilling.
4. Drill out all holes using a 5/16” drill being careful not to ream out the holes to a larger diameter as self tapping screws are used for mounting.
5. Raise the Rock Bars into position and install all bolts tightening the bottom rear bolts first. Be careful not to over-tighten.
6. Move to the other side and repeat the procedures outlined above.
7. When finished be sure to go back and check the tightness of all bolts.

Note: KNIGHTGUARD

1. **Ford applications use existing holes in pinch weld.**
2. **Chevy HD & _ ton has U-bracket on drivers side rear.**