

## CARGO HITCH RACK INSTALLATION INSTRUCTIONS

**IMPORTANT:** 2" Receiver hitch required to install and use this product.

- 1. Begin by bolting the mount plate and the cargo basket together. The mounts have pre-existing holes and mounting hardware is included in the kit.
- 2. If you do not already have a hitch pin, you will need to get one from an auto parts store. We recommend using a locking hitch pin to deter theft.
- 3. Install by sliding rack stinger into hitch and pin into place.

## THANK YOU FOR PURCHASING WARRIOR PRODUCTS

Learn more about trailer hitches and towing we have.