



# WAR 861

## TOW BAR –BUMPER ADAPTER

### INSTALLATION INSTRUCTIONS

NOTE: Please read all instructions before starting installation.

Your Tow Bar Bumper Adapter should be installed by a professional installer or fabricator experienced at installing tow bars, and at wiring in lights on the tow vehicle. Points that need close attention:

1. Using your Brackets as templates, mark mounting surface and drill ½” holes. The brackets must be at least 24” apart.
2. Fabricate a structure on the towed vehicle so that the Tow Bar is pulling on the frame only. As the Tow Bar will be attached to the bumper, fabricate a support to the frame similar to a winch attachment.
3. Bolt brackets with supplied ½ x 1 ½” grade 5 bolts. Use large flat washers and 2-way lock nuts on the inside of mounted part. Torque bolts to 75 ft lbs.
4. **Congratulations! Now you’re ready to attach your Warrior Products Tow Bar.**

.....  
*“Your Knight in Shining Armor!”*