



Protecting Your Adventure Lifestyle

SAFARI SPORT RACK BASKET INSTALLATION INSTRUCTIONS WAR 876

'04 & Up Jeep Unlimited

Read all instructions before proceeding.

When installed with the Safari Canoe Rack the suggested weight capacity is 400 lbs., with weight distributed evenly over the entire area of the rack. If severe off road conditions are prevalent, because of side sway on severe side hill driving conditions, capacity should not exceed 150 lbs.

1. Assemble the two halves of the Basket using the four 1/2" X 7/16" bolts provided. Once assembled, position the Warrior decal centered across the joints on each side and press on.
2. Remove rear Light Bar top section at the snapper pins
3. Lift the basket into place on top of the vehicle. Slide basket mounting tabs onto the front Light Bar. **Do not** mark holes for drilling at this time.
4. Slide rear Light Bar, removed in step #2, into basket mounting tabs on rear of basket.
5. Make sure basket is centered side to side. Using basket mounting tabs as a guide, drill 3/8" holes through front and rear mounting hoops. Install bolts, flat washers, lock washers, and nuts, and then tighten.
6. After a test drive, recheck tightness of all bolts and you are done!

THANK YOU FOR PURCHASING WARRIOR PRODUCTS