



Protecting Your Adventure Lifestyle

Tube Door Limiting Strap Installation Instructions INSTALLATION INSTRUCTIONS

KIT CONTENTS:

Description	Qty	Description	Qty
Installation Sheet	1	Small Metal Screws	4
Nylon Straps	2	Footman Loops	2

INSTALLATION

Note: Your tube doors need to be installed on the vehicle to complete this project.

1. Hook the closed loop of the nylon strap over the factory door strap hook of the Jeep
2. Wrap the Velcro loop around the metal footman loop, centering the Velcro pieces on each other.
3. Hold your door as far as you would like it to open
4. Place the footman loop on the bottom tube of the tube door facing the inside of the vehicle and locate it so that there is tension on the strap
5. Mark the location of the holes for drilling, and remove the footman loops from the nylon strap
6. Remove the tube door and drill the two marked holes with a 5/32" drill bit.
7. Screw the footman loop into place using the supplied screws.
8. Re-install the tube door and slide strap into the footman loop. Use Velcro portion to adjust as needed.
9. Repeat steps 1-8 on second tube door.

Installation is complete

