



Protecting Your Adventure Lifestyle

Safari Tube Doors Mesh Cover INSTALLATION INSTRUCTIONS

Read all instructions before proceeding.

NOTE: Fits all applications where Safari Tube Doors are installed.

1. Remove **Warrior's Deluxe Tube** door from your vehicle and remove the paddle handle from the tube door.
2. Lay the door down with the outside up and lay out the mesh cover on top of the door with the straps going inward.
3. Attach the velcro straps tightly around the tube door.
4. Install the paddle handle by carefully cutting through the mesh with a razor blade or scissors on the inside of the paddle handle mounting plate. Install the paddle handle over the mesh from the outside and bolt it back on. Reinstall the door on your vehicle.
5. **Economy Doors:** remove the door from your vehicle and follow instructions number 2 and 3. Now reinstall your Tube doors on your vehicle.

Enjoy your new Warrior Safari Tube Door Mesh Covers.

QUALITY



INTEGRITY



INNOVATION



SERVICE

Learn more about armor and protection we have.