



Protecting Your Adventure Lifestyle

Universal Mud Flaps **Installation Instructions**

IMPORTANT: Mud flaps are only included in the 4000 kit. If you have the 4005 kit or choose to not use the mud flaps provided, you should be able to purchase mud flaps of your choice at any local auto/truck parts store.

INSTALLATION

1. These mud flaps will help minimize road debris from your tires being kicked up into traffic and keep material from them directed back to the road. The brackets are not side specific, so take either one of them and find a suitable mounting location on the side of the frame rail. Make sure your chosen location allows you access the backside for threading of the hardware. Take note of any suspension components or exhaust that may be in the way of the brackets or the mud flaps. The mud flaps should also be positioned a few inches away from the tires.
2. Holding the brackets up to the frame rail, use a marker or scribe to indicate where you will be drilling for the mounting hardware. Set the bracket aside and drill the mounting holes with a 3/8" drill bit. Deburr the holes and touch up the bare metal with some suitable paint to prevent rust.
3. Once the paint has dried properly, use the 3/8" hardware and bolt the brackets to the frame rail. Now take the sleeve tube and using the 5/16" hardware, attach the mud flaps. There is a long bar with four holes in it that will go on the other side of the sleeve tube tab, sandwiching the mud flap material in between.
4. Slide the sleeve tube onto the bracket bar and tighten down the set screw in the desired location. They are easily removable by loosening the set screw, sliding the sleeves off the bracket bars and storing the mud flaps inside the vehicle.

This completes the installation of your new Warrior Products Universal Mud Flap Kit.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS

QUALITY • INTEGRITY • INNOVATION • SERVICE