



Protecting Your Adventure Lifestyle

---

---

## 07-15 JK 4DR CENTER CAGE NET 40500

**Note:** This center cage netting kit has coverage from the soundbar to the top of the tailgate. For side coverage of the cargo area, Warrior also offers the 40600 Side Cage Net kit. A 40800 Basic Cargo Cover which spans the top of the tub is also available.

### **Tools needed**

Cordless Drill  
Center Punch  
7/64" Drill Bit  
3/16" Drill Bit  
Phillips Screwdriver  
Socket Wrench  
3/8" socket  
Measuring Tape  
Marker Pen

### **Supplied Parts**

(1) Center Cage Net  
(1) Sound Bar Anchor Bracket  
(4) Footman Loop  
(8) Plastic Clip Buckle  
(4) 1" Velcro Wrap Strap  
(2) 14# x 1" Self Tap Screw  
(8) #10 x 1/2" Oval Head Sheet Metal Screw

### **Installation:**

1. To begin the installation process you must remove the two Freedom Top panels. It is not necessary to completely remove the hard top, but it does make the process easier if you do. If your Jeep is equipped with a soft top, fold it back so you can access the top of the sound bar.
2. Take the Sound Bar Anchor Bracket and slip it between the metal structure of the sound bar and the forward plastic lip of the Jeeps' sound bar housing. You'll need to pull back a little bit of the sound bar padding to access the ends where you'll be drilling. Center and set the top edge of the bracket (minus the loops) flush with the top of the metal structure of the sound bar. Make marks through the two mounting holes with a marker pen, tap with a center punch and drill with a 3/16<sup>th</sup> drill bit. Utilize the (2) #14 size self-tapping screws and affix the bracket to the soundbar structure.
3. The (4) Footman Loops will now be screwed into the top inside edge of the tailgate. Open the tailgate wide so you can access the inside upper surface of the tailgate. Using the measuring tape, place the footman loops in the locations shown in the image. Make your marks through the mounting holes of the footman loops, then center punch and drill them out with a 7/64<sup>th</sup> drill bit. Screw the footman loops down onto the tailgate with the #10 x 1/2" sheet metal screws.



**QUALITY**



**INTEGRITY**



**INNOVATION**



**SERVICE**



Protecting Your Adventure Lifestyle

- 
4. Drape the Center Cage Net over the rear roll bar with the 'WP' logo over the rear cargo area and facing out. Take the three forward Velcro straps and feed them between the hard top and the sound bar so they can be inserted through the mounting slots of the sound bar anchor bracket. Fold the straps back upon themselves and affix the Velcro securing the three center straps.
  5. The next step is the part of the process that will be easier if the hardtop is not on the Jeep. The forward corners have diagonal straps that need to go around the ends of the sound bar and roll bar. (See image)
  6. Once these (5) anchor points have been situated, proceed with wrapping the remaining straps where they lay against the roll bar. It works best to just loosely wrap each strap until you have them all positioned and then do a final tightening.
  7. There are 4 Velcro wrap straps with clips that install around the diagonal sections of the roll bar and 4 nylon webbing straps with clips that go through the footman loops attached to the tailgate. Note: We recommend not having the tailgate straps clipped when running the hardtop as this configuration will prevent the tailgate from opening.



**THANK YOU FOR PURCHASING WARRIOR PRODUCTS**

**QUALITY**



**INTEGRITY**



**INNOVATION**



**SERVICE**

If you're looking for quality soft tops and hard tops, visit our website.