



Protecting Your Adventure Lifestyle

UNIVERSAL BRUSH GUARD

INSTALLATION INSTRUCTIONS

WAR 59000 SERIES

READ ALL INSTRUCTIONS BEFORE PROCEEDING.

1. Position your Warrior Universal Brush Guard on the top flat surface of your bumper. Take care to center it with mounting brackets adjusted forward or back to accommodate your particular bumper design.
2. Mark through the mounting brackets for drilling.
3. Remove the Universal Brush Guard and drill 3/8" holes where indicated by marks. Be sure to use safety glasses.
4. Reposition the Universal Brush Guard over the mounting holes and install using the 3/8" bolts, washers, and lock nuts provided. Make sure all bolts are tight.
5. After a test drive, re-check tightness of all bolts and you're done!

Enjoy your new Universal Brush Guard by Warrior Products!