



Protecting Your Adventure Lifestyle

---

---

## 800022 REAR U-BOLT KIT – JEEP YJ **INSTALLATION INSTRUCTIONS**

**Please read instructions before beginning installation.** Check the kit hardware against the parts list. Be sure you have all needed parts and know where they go.

1. Raise the rear of the vehicle and support with safety stands. Make sure the vehicle cannot roll.
2. Remove the rear wheels and tires. Remove stock shocks.
3. Support the rear axle housing with a floor jack (you must have stands under frame supporting vehicle weight).
4. Loosen the four rear spring to axle U-bolts. (The remainder of the spring removal and installation is performed one side at a time.)
5. On the driver side position a floor jack beneath the axle tube, just inside of the leaf spring. Raise the jack until the axle just separates from the spring. Now remove the rear spring U-bolts. Repeat on the other side.
6. Install new rear spring U-bolts lowering the jack supporting the axle to tighten. Torque bolts to 65 ft/lbs.

### PARTS LIST

1/2" X 6 1/2" X 2 1/2" U-Bolts	1/2" Tall Lock Nuts (8)
700008 (4)	1/2" Flat Washers (8)

**QUALITY • INTEGRITY • INNOVATION • SERVICE**

Learn more about performance suspension parts we have.