



Protecting Your Adventure Lifestyle

90764 Paddle Handle Snubber Kit Fits '07+ Wrangler Adventure Doors Installation Instructions

Contents:	Qty	Contents:	Qty
Snubber Bracket	2	#10-24 Nylock Nuts	2
Rubber Snubber	2	#10 SAE Flatwasher	6
#10-24 x 3/4" Black Machine Screws	10		

Note: Installation of the 90764 Paddle Handle Snubber Kit is fairly straightforward and should only require the removal and replacement of the paddle handle mounting screws. Some minor adjustment of the snubber bracket may be necessary to find the optimal amount of pressure exerted against the door jamb. This may be accomplished by adding or subtracting washers between the snubber and the bracket (washers provided).

Installation: (Installation process is the same for both front and rear Adventure Doors)

1. Begin by removing the (4) screws that hold the paddle handle assembly to the Adventure Door. It is not necessary to actually remove the paddle handle from the door... just the screws. Replace with the longer _" screws provided, place the snubber bracket over the screws from the inside and rethread and tighten on the original Nylock nuts. (See Fig. 1 for bracket orientation)
2. Insert a _" screw through a rubber snubber from the larger opening end so the head of the screw is fully seating within the snubber. Place the threaded end through the hole on the bracket and tighten with a locknut provided. Do not over-tighten as you risk crushing the rubber snubber. Just snug it up.



3. Be certain the paddle handle latch mechanism is in the 'open' configuration and then gently close the Adventure Door taking note of anything that may be making unnecessary contact. You want the snubber to compress just enough to prevent the door from rattling, but not so much that it causes the paddle handle to 'stick' and make opening the door difficult. (See Fig. 2)
4. If you need more pressure against the snubber you can add a washer or two between the snubber and the bracket. Repeat steps for remaining doors and your installation is complete.

Adventure Door Accessories – Warrior also offers a door limiting strap kit for your Warrior Adventure Doors. This simple and inexpensive strap kit will prevent your doors from opening too far and hitting your Jeep or damaging the paint. Part #90797 fits Warrior Adventure Doors for 87-96 Wrangler (#90771 & #90772). Part #90798 fits Warrior Adventure Doors for '07+ Wranglers (#90773).

QUALITY • INTEGRITY • INNOVATION • SERVICE

Discover other replacement doors and components on our website.