



Protecting Your Adventure Lifestyle

---

## **07-10 JK Dashboard Overlay** **Installation Instructions**

Installation of these is quite simple and can be done with a handheld screwdriver, but a powered screwdriver makes it much easier. You should have 4 panel pieces and 16 Phillips head stainless screws.

### **INSTALLATION**

1. Start at the bottom and work your way up. Hold your lowest panel in place so that it is lined up correctly around the holes for your 12v outlets and the buttons between. You can drive the screws in now with the panels in place, or mark them, set the panel aside and run the screws in where you marked.
2. Once you have the bottom panel in place, repeat the process for the next 3 panels. Again, be sure you are working your way up from the bottom.
3. Once all 4 panels are in place, your installation is complete.

This is the standard installation for this part. If you would prefer, you can try to install them with two sided tape. Your results in this method may not be the best as the dash is curved and the flat panels are pulled in to match the curve by the screws.

