



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

US Patent# US 7,263,961B2

Part #'s **Secret Weapon: 601-155**

Application : **2006-2009 Chevy Trailblazer, GMC Envoy, Isuzu Ascender 4.2L**

Parts List : **2 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter 3" Tall filter / 1 x 15mm x 12" Hose
3 x 3"- 3" Coupler / 1 x Intake System Bracket with rubber bushing / 6 x 3" Clamp**

- 1 Remove bolts securing OEM air intake, and tube! Loosen clamps on OEM rubber intake pipe.
 - 2 Remove 15mm PCV hose from from OEM intake and engine.
 - 3 Remove Air Injection Hose from side of airbox and and set aside
 - 4 Unplug mass air sensor, and Remove OEM airbox lid by lifting up on OEM airbox lid
 - 5 Remove the OEM rubber intake tube
 - 6 Unbolt mass air sensor from OEM air intake tube and put aside
 - 7 Remove rest of OEM airbox to expose throttle body
 - 8 Wipe the throttlebody clean of any grease, install the 3"-3" coupler onto throttlebody, secure with OEM clamp.
 - 9 Install the WR intake tube with no vacum ports on it into 3" side of coupler and clamp down
 - 10 Install 3"-3" Coupler into the installed WR pipe and clamp down
 - 11 Take MAF sensor and bolt into Weapon-R plate adapter on intake tube and screw down
 - 12 Install WR pipe with MAF installed into it and slide inot the 3"-3" coupler and clamp down
- NOTE! Make sure Straight WR Pipe with MAF has the vacum ports towards the throttle body for correct MAF flow!**
- 13 Measure the OEM PCV hose, replace with supplied 15mm hose, install from PCV port to intake pipe.
 - 14 Reinstall Air injection Hose to Large port on WR pipe and clip into port
 - 15 Reconnect MAF wire harness back into MAF sensor
 - 16 Install 3" coupler onto Secret Weapon air filter, secure with supplied clamp.
 - 17 Install filter assembly onto the end of Weapon*R pipe, secure with OEM clamp.
 - 18 Install U-shaped part of intake system bracket under the clamp on air filter.
 - 19 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
 - 20 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
 - 21 Secure with washer and nut included in bracket kit.
 - 22 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
 - 23 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
 - 24 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.(If Applicable)



Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

Discover other air intake systems on our website.