



Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s **Hyper Intake : 904-123 / Dragon Intake : 804-123**

Application : **2003-2005 NISSAN 350Z**

(2003-2004 350Z #D-489-2 ONLY)

Parts List : **1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter / 2 x 3" coupler**
1 x Intake Bracket kit / 1 x 3" Clamp/ 1x Blank MAF adapter plate with 4 bolts

Note: Additional Parts needed when you have a Dragon Filter, 1 x 3"-3" Coupler / 2 x 3" Clamp

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the 15mm PCV hose from OEM intake.
- 3 Unplug and remove the MAF sensor unit from the OEM air intake system, put aside.
- 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 5 Install the 3" coupler onto throttlebody, secure with OEM clamp.
- 6 Insert Weapon*R intake pipe into the coupler, secure with clamp.
- 7 Install the OEM 15mm hose onto the Weapon*R intake pipe.
- 8 Install the 3"-3" coupler onto MAF unit and clamp down..
- 9 Insert MAF unit into end of WR intake intake tube, and clamp down
- 10 Install MAF bracket onto OEM unit and bolt down with 4 supplied bolts.
- 11 Install the Weapon*R Hyper filter onto Weapon*R MAF adapter plate.
Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.
- 12 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 13 Install filter assembly onto the MAF bracket plate, secure with OEM clamp.
- 14 Install U-shaped part of intake system bracket under the clamp on air filter.
- 15 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 16 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 17 Secure with washer and nut included in bracket kit.
- 18 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 19 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 20 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

(GREY TYPE MAF PLUG)

