



Recommended Air Filter Cleaning Intervals: 3000 Miles.
US Patent# US 7,263,961B2

Part # 's Secret Weapon : 301-112

Application : 1990-93 Acura Integra

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R [Air Filter](#) / 1 x 10mm x 24" Hose / 1 x 4mm x 12" Hose
1 x 2.5"- 3", 1 x 3"-3" Coupler / 1 x Intake System Bracket kit / 3 x 3" Clamp / 1 x 3way Tee valve,

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the coolant transfer / PCV hardline from from OEM intake and engine.
- 3 Mark the coolant tranfer hose origins, install the 10mm hose supplied in kit to those 2 locations.
- 4 Remove OEM 4mm TPS hose from OEM rubber intake tube and throttlebody.
- 5 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 6 Wipe the throttlebody clean of any grease, install the 2.5"-3" coupler onto throttlebody, secure with OEM clamp.
- 7 Insert Weapon*R intake pipe into the 3" end of the 2.5"-3" coupler, secure with clamp.
- 8 Measure and cut to length the PVC & 4mm TPS hose removed, from point of origin and to Weapon*R intake pipe,
- 9 Install the hoses from their point of origin and onto the Weapon *R intake pipe.
- 10 Install the Weapon*R Hyper filter onto the end of the intake pipe.
Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.
- 11 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 12 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
- 13 Install U-shaped part of intake system bracket under the clamp on air filter.
- 14 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 15 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 16 Secure with washer and nut included in bracket kit.
- 17 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 18 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 19 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note : Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

