



Recommended Air Filter Cleaning Intervals: 3000 Miles.

**Part # 's Secret Weapon Intake #301-120**

**Application : 1998-99 Acura CL /98-02 Honda Accord / 1998 Odyssey/ 97-01 Prelude : 4 Cylinder  
(1998-2002 ODYSSEY 4CYL AND 97-2001 PRELUDE #D-489-2 ONLY)**

**ARB # D-489-2 98-2002 ACCORD 4CYL ONLY (The following engine families are  
excluded from the ARB# SULEV / LEV2 2001 & 2002 1HNXV02.3BF9 & 2HNXV02.3FK6)**

**Parts List : 1 x Weapon\*R Intake pipe. / 1 x Weapon\*R [Air Filter](#) / 1 x 10mm x 24" Hose  
1 x 2.5"- 3" Coupler / 1 x Intake System Bracket kit / 1 x 3" Clamp**

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Mark the coolant transfer hose origins
- 3 Remove the coolant transfer / PCV hardline from OEM intake and engine. Replace with the 10mm hose supplied in kit to those 2 locations.
- 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 5 Wipe the throttlebody clean of any grease, install the 2.5"-3" coupler onto throttlebody, secure with OEM clamp.
- 6 Insert the intake pipe into 2.5"-3" coupler on throttlebody, secure with supplied clamp.
- 7 Install the other end of PVC hose onto the Weapon \*R intake pipe.
- 8 Install the Weapon\*R Hyper filter onto the end of the intake pipe.
- 9 **Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 10 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.  
Install filter assembly onto the end of Weapon\*R intake pipe, secure with OEM clamp.
- 11 Install U-shaped part of intake system bracket under the clamp on air filter.
- 12 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
- 13 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 14 Secure with washer and nut included in bracket kit.
- 15 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 16 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 17 Place Weapon\*R CARB Sticker on a visible place in engine compartment. ( If Applicable )

**WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

**Note:** Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from.  
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

