



Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s **SECRET WEAPON INTAKE : 301-139**

US Patent# US 7,263,961B2

Application : **98-02 HONDA PASSPORT / ISUZU RODEO V6 3.2L**

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R [Air Filter](#) / 1 x 10mm x 24" Hose
1 x 2.5"- 3" Coupler / 2 x 3" Coupler / 1 x Intake System Bracket kit / 6 x 3" Clamp
1 X AIT GROMMET / 1 X Aluminum sheet metal cast elbow

Note: Additional Parts needed when you have a Dragon Filter, 1 x 3"-3" Coupler / 2 x 3" Clamp

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove 10mm port hose on OEM tube.
- 3 Remove and set aside OEM MAF sensor.
- 4 Disconnect the OEM AIT sensor harness , remove from OEM rubber intake pipe.
- 5 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 6 Wipe the throttlebody clean of any grease, install the 2.5"-3" coupler onto throttlebody, secure with OEM clamp.
- 7 Insert the WR elbow pipe into 2.5"-3" coupler on throttlebody, secure with supplied clamp.
- 8 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to WR elbow pipe.
- 9 Install 3"-3" coupler onto the end of WR elbow bend, and secure with clamp
- 10 Install WR straight pipe into 3" coupler and clamp down
- 11 Install 3"-3" coupler onto the end of WR pipe, and secure with clamp
- 12 Install MAF sensor unit into 3" coupler and clamp down
- 13 Install the Weapon*R Hyper filter onto the MAF sensor

Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.

- 14 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 15 Install filter assembly onto the MAF sensor, secure with clamp.
- 16 Install U-shaped part of intake system bracket under the clamp on air filter.
- 17 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 18 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 19 Secure with washer and nut included in bracket kit.
- 20 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 21 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 22 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

