



Part # 's **Secret Weapon: 301-154**

Application : **2003-08 Honda FIT 1.5L**

Recommended Air Filter Cleaning Intervals: 3000 Miles.

US Patent# US 7,263,961B2

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R [Air Filter](#) / 1 x 10mm x 24" Hose/ 1 x AIT Grommet
1 x 2.5"- 3" Coupler / 1 x 2.75"-2.75" Coupler / 1 x Intake System Bracket kit / 3 x 3" Clamp

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the coolant transfer / PCV hardline from from OEM intake and engine.
- 3 Mark the coolant transfer hose origins, install the 10mm hose supplied in kit to those 2 locations.
- 4 Disconnect the OEM AIT sensor harness , remove from OEM rubber intake pipe.
- 5 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 6 Wipe the throttlebody clean of any grease, install the 2.5"-3" coupler onto throttlebody, secure with OEM clamp.
- 7 Insert the intake pipe into 2.5"-3" coupler on throttlebody, secure with supplied clamp.
- 8 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)
- 9 Install AIT Grommet into WR intake pipe hole.
- 10 Insert the OEM AIT sensor into the AIT Grommet on Weapon*R intake pipe, reconnect AIT harness.
- 11 Install the hoses from their point of origin and onto the Weapon *R intake pipe.

Note: Secret Weapon Filter Option

- 13 Install 3" coupler onto Secret Weapon air filter, secure with supplied clamp.
- 14 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
- 15 Install U-shaped part of intake system bracket under the clamp on air filter.
- 16 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 17 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 18 Secure with washer and nut included in bracket kit.
- 19 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 20 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 21 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

