



Recommended [Air Filter](#) Cleaning Intervals: 3000 Miles.

Part # 's **Secret Weapon: 301-157**

Application : **2006 Honda S2000**

US Patent# US 7,263,961B2

Parts List : 1 x Weapon*R 3.5" Intake pipe. / 1 x Weapon*R 4" Air Filter / 1 x 10mm x 24" Hose
1 x 3.5"-3" Coupler / 1 x 3.5"-4" coupler/ 1 x Intake System Bracket kit / 3 x 3.5" Clamp
1 x 3"-3" clamps

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the coolant transfer / PCV hardline from from OEM intake and engine set aside.
- 3 Disconnect the AIT sensor harness. Then remove the AIT from the intake tube and put aside.
- 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 5 Wipe the throttlebody clean of any grease or dirt, install the 3"-3.5"coupler onto throttlebody, secure with clamp.
- 6 Insert the intake pipe into 3.5" side of coupler on throttlebody, secure with supplied clamp.
- 7 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
- 8 Install AIT into the Grommet on WR pipe.
- 9 Install the AIT sensor harness onto sensor and clip on.

Note: Secret Weapon Filter Option :

- 10 Install 3.5" -4"coupler onto Secret Weapon air filter, secure with supplied clamp.
- 11 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
- 12 Install U-shaped part of intake system bracket under the clamp on air filter.
- 13 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 14 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 15 Secure with washer and nut included in bracket kit.
- 16 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 17 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 18 Place Weapon*R CARB Sticker on a visible place in engine compartment. (**If Applicable**)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

