



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Secret Weapon: 303-123**

US Patent# US 7,263,961B2

Application : **2003-06 Mitsubishi Lancer Evolution Turbo**

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter 4" / 1 x 8mm x 12" Hose / 1 x 4mm x 12" Hose
1 x 1" x 4" Hose / 1 x 3" Coupler / 1 x 2.5"-3" / 1 x Intake System Bracket kit / 3 x 3" Clamp
1 x 4"-4" Coupler / 2 x 4" Clamp / 1 x AFM Adapter

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Disconnect and remove the PVC hose from OEM intake and engine.
- 3 Disconnect original blow off valve line and put aside.
- 4 Disconnect Air check valve 4mm line from airbox and put aside.
- 5 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 6 Wipe the turbo inlet clean of any grease, install the 2.5"- 3" coupler onto the turbo inlet, secure with OEM clamp.
- 7 Insert Weapon*R intake pipe into the 3" end of the 2.5"- 3" coupler, secure with clamp.
- 8 Install OEM 4mm line from air check valve to port on WR intake tube.
- 9 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
- 10 Use 1" silicone hose provided to reconnect OEM blow off valve.
Note: If aftermarket blow off valve is used , cap off 1" port on WR tube, this port not used with aftermarket part.
- 11 Install 3" coupler onto end of WR intake pipe , clamp down.
- 12 Reconnect AFM unit into end of 3" coupler and clamp down.
- 13 Install WR MAF adapter to OEM MAF sensor and bolt down using 4 nuts and bolts provided.
- 14 Install 4" coupler onto Secret Weapon air filter, secure with supplied clamp.
- 15 Install filter assembly onto the end of Weapon*R MAF plate , secure with 4" clamp.
- 16 Install U-shaped part of intake system bracket under the clamp on air filter.
- 17 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 18 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 19 Secure with washer and nut included in bracket kit.
- 20 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 21 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 22 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

