



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Secret Weapon Intake : 303-127**

US Patent# US 7,263,961B2

Application : **2007-2009 Outlander V6**

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter 3" / 1 x 15mm x 12" Hose
1 x 3"-3" Coupler / 1 x 2.5"-3" Coupler / 1 x Intake System Bracket kit / 4 x 3" Clamp

- 1 Remove three 10mm bolts securing resonator. Remove one 10mm bolt securing front of air box, and two plasticpop fasteners securing air scoop. Disconnect PCV hose from intake hose. Loosen clamp on throttle body. Remove resonator and air scoop, then remove air box and hose together.
- 2 Unbolt MAF sensor from OEM air box. Set sensor aside for later steps. Wipe inside of throttle body clean of any oil residue or dirt. Take 2.5"-3" coupler and secure it onto throttle body with OEM clamp. Insert Weapon*R intake pipe into coupler, and secure with supplied clamp.
- 3 Insert MAF sensor into Weapon*R intake pipe, making note of air flow direction on sensor. Secure sensor to pipe with OEM screws. Reconnect sensor wire. Secure 3"-3" coupler onto end of Weapon*R filter. Install filter onto end of WR intake pipe and clamp down. Secure supplied rubber screw into nearest 10mm hole. Hook supplied bracket onto clamp, and slide onto 3" side 3" coupler clamp. Bend bracket to reach rubber screw. Cut off any excess bracket, and secure to rubber screw. Insert Weapon*R air filter into coupler, and secure with clamp.
- 4 Check all clamps and connections for leaks, and clearances around intake before driving. Allow engine computer to adjust for at least 5 minutes before any high revving of engine.

