



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Secret Weapon: 304-121**

US Patent# US 7,263,961B2

Application : **2002-2007 NISSAN ALTIMA / 2002-08 MAXIMA / 2003-06 MURANO 3.5L**

Parts List : 1 x Intake pipe. / 1 x [Air Filter](#) / 3 x 3" coupler / 1 x 15mm x 12" hose
1 x Intake Bracket kit / 5 x 3" Clamp / 1 x AFM-NS2 Adapter plate

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the 15mm PCV hose from OEM intake.
- 3 Unplug and remove the MAF sensor from the air intake system.
- 4 Unplug AIT harness and remove the AIT sensor from OEM airbox.
- 5 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 6 Install the 3" coupler onto throttlebody, secure with OEM clamp.
- 7 Insert Weapon*R intake pipe into the coupler, secure with clamp.
- 8 Install the supplied 15mm hose onto the intake pipe and to the PCV valve on valvecover.
- 9 Install the 3" coupler onto end of intake pipe, secure with clamp.
- 10 Insert MAF into the 3" coupler, secure with clamp, connect MAF harness.
- 11 Line up the holes on MAF to the AFM-NS2 adapter plate, secure with nuts and bolts in kit.
- 12 Tie AIT sensor to any wire harness on fender well, to measure ambient air temperatures.
- 13 Install the Weapon*R Hyper filter onto AFM adapter plate..
- 14 **Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 15 Install filter assembly onto the AFM adapter plate, secure with OEM clamp.
- 16 Install U-shaped part of intake system bracket under the clamp on air filter.
- 17 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 18 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 19 Secure with washer and nut included in bracket kit.
- 20 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 21 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 22 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Note: Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

