



Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Secret Weapon: 304-124**

US Patent# US 7,263,961B2

Application : **1990-97 Nissan Truck 2.4L / 1998-04 FRONTIER / XTERRA 4 CYL. ONLY**

Parts List : 1 x Intake pipe. / 1 x [Air Filter](#) / 2 x 3" coupler / 3 x 3" Clamp, 1 Aluminum box/ 1 x AIT grommet

- 1 Loosen the clamps on the air cleaner assembly. Remove the air cleaner hose.
- 2 Remove the 2 butterfly nuts on top of the Air cleaner assembly, remove the air cleaner top.
- 3 Remove the air resonator box from fender well.
- 4 Remove the OEM hoses on the lower air cleaner assembly , remove the lower air cleaner assembly.
- 5 Remove the round rubber gasket on the lower air cleaner assembly.
- 6 Install the round rubber gasket onto the Weapon*R aluminum airbox.
- 7 Install the Weapon*R aluminum airbox onto the throttle body, tighten the airbox down with OEM butterfly nuts.
- 8 Re-Install the OEM hoses onto the Weapon*R airbox.
- 9 Install the 3" coupler onto the 3" tube on the Weapon*R airbox.
- 10 Install the Weapon*R intake pipe into the 3" coupler, secure with supplied clamps.
- 11 Install the Weapon*R filter onto end of intake pipe.
- 12 **NOTE: Leave AIT sensor in OEM resonator hose.**
Or use AIT grommet and drill 5/8 inch hole towards filter end and use grommet for AIT sensor(pictured)
Note: Secret Weapon Filter Option :
- 13 Install 3" coupler onto Secret Weapon air filter, secure with supplied clamp.
- 14 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 15 Slide the Mounting bracket welded on the intake pipe onto the rubber mounting grommet.
- 16 Secure the bracket to the rubber mounting grommet with supplied hardware.
- 17 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 18 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 19 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

