



Part # 's **Secret Weapon: 304-128**

Application : **2001 Maxima V6**

Recommended Air Filter Cleaning Intervals: 3000 Miles.

US Patent# US 7,263,961B2

Parts List : 2 x Intake pipe. / 1 x [Air Filter](#) / 3 x 3" coupler / 1 x 4mm x 12" hose / 1 x 10mm/ Blank AFM Plate
1 x 15mm x 12" hose / 1 x 2.5"- 3" Coupler / 1 x Intake Bracket kit / 5 x 3" Clamp/ 1 x pipe with grommet

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the 15mm PCV and 10mm Air recirculator hoses from OEM intake.
- 3 Remove the 4mm hose from the air resonator box on OEM intake pipe.
- 4 Unplug and remove the MAF sensor from the air intake system.
- 5 Unplug AIT harness and remove the AIT sensor from OEM airbox.
- 6 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 7 Install the 2.5-3" coupler onto throttlebody, secure with OEM clamp.
- 8 Insert Weapon*R intake pipe into the coupler, secure with clamp.
- 9 Install the supplied 15mm hose onto the intake pipe and to the PCV valve on valvecover.
- 10 Install the supplied 10mm hose onto the intake pipe and to the air recirculator valve.
- 11 Install the supplied 4mm hose onto the intake pipe and to the air resonator box.
- 12 Install the 3" coupler onto end of intake pipe, secure with clamp.
- 13 Insert MAF into the 3" coupler, secure with clamp, connect MAF harness.
- 14 Line up the holes on MAF to the AFM-Blank adapter plate, secure with nuts and bolts in kit.
- 15 Install 3"-3" coupler onto MAF plate clamp down, and install WR tube with AIT grommet.
- 16 Re-install AIT sensor into grommet and plug harness into AIT sensor.
- 17 Install the Weapon*R Hyper filter onto AFM adapter plate..
Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.
- 18 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 19 Install filter assembly onto the WR intake pipe, secure with OEM clamp.
- 20 Install U-shaped part of intake system bracket under the clamp on air filter.
- 21 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 22 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 23 Secure with washer and nut included in bracket kit.
- 24 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 25 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 26 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

