WR WEAPON·R
COMPETITION PRODUCTS ®

Part # 's SECRET WEAPON INTAKE: 304-130   US Patent# US 7,263,961B2

Application : **2006-2007 Infinity M45**

Parts List : **1 x Weapon*R Intake pipe.   / 1 x Weapon*R Air Filter 4" / 1 x 15mm x 12" Hose/ 1 x 4mm hose**
1 x 3.5"-3.5" Coupler / 1 x 3.5"-4" Coupler/ 1 x Intake System Bracket kit / 4 x 4" Clamp

1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
2 Remove PCV hose from OEM intake and engine, also 4mm hose from OEM intake
3 Disconnect the MAF sensor harness, carefully remove MAF sensor from OEM airbox,
4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
7 Wipe the throttlebody clean of any grease, install the 3.5"-3.5"" coupler onto throttlebody, secure with OEM clamp.
8 Insert Weapon*R intake pipe into the 3.5"" coupler, secure with clamp.
9 Measure 3" and cut a piece of the WR 15mm vacume line. Use to replace OEM pvc tube to the WR intake pipe.
  Measure 3" and cut a piece of the WR 4mm vacume line. Use to replace OEM 4mm line.
10 Install MAF sensor into Weapon*R intake pipe, reconect MAF sensor harness.
   Note: Secret Weapon Filter Option :
11 Install the 3.5"- 4" coupler onto the end of the intake pipe, stretch if needed secure with supplied clamp.
12 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
13 Install U-shaped part of intake system bracket under the clamp on air filter.
14 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
15 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
16 Secure with washer and nut included in bracket kit.
17 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
18 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
19 Place Weapon*R CARB Sticker on a visible place in engine compartment. **(If Applicable)**